


STRINGING INSTRUCTIONS



RED, SILVER & BLACK



String Instructions

2-Piece Stringing

String tension: 30 +/- 4
 String pattern: DPR 16 x 19
 Length: 23' Mains x 15' Crosses

Mains

Mount the racquet to the stringing machine with Ektelon logo on the handle facing up. Start at head. M's skip at 5H, 7H, 9H, 10H, 12H, 13H, and 14H.

Short Side

1. 1H-L to left Pin 1
2. Left pin 1 to 2H-L (tension and clamp)
3. 1H-R to right Pin 1
4. Right pin 1 to 2H-R (tension and clamp)
5. 3H-L to left Pin 2
6. Left pin 2 to 4H-L (tension and clamp)
7. 3H-R to right Pin 2
8. Right pin 2 to 4H-R (tension and clamp)
9. 6H-L to left Pin 3
10. Left pin 3 to 8H-L (tension and clamp)
11. 6H-R to right Pin 3
12. Right pin 3 to 8H-R (tension and clamp)
13. 11H-L to left Pin 4
14. Left pin 4 to 15H-L (tension and clamp) and tie-o at 11H-L
15. 11H-R to right Pin 4
16. Right pin 4 to 15H-R (tension and clamp) and tie-o at 11H-R

Crosses

1. Tie starting knot at 6H-R
2. Start at 5H-R and weave across to 5H-L, then down to 7H-L and across to 7H-R.
3. Continue installing cross strings conventionally. Finish and tie o at 4T-L.

* It is recommended to use a table-brake when stringing cross strings on all O3 Racquets.