

Racquets

Wilson Ugly Stick 165 BLX
Wilson K Boom 165
Wilson 2013 Big Stick 170 BLX

Tension	Pattern	Start M's	Mains Skip
29-34	14 x 18	T	7H ONLY

Length 1pc	40'
Short Side	12'
Length 2pc	24'x16'
Tie Off M's	4H
Start 1pc X	5H
Last 1pc X	5T
Tie 1pc X	4T
Start 2pc X	5H
Last 2pc X	5T
Tie 2pc X	2H,4T

Notes	<p>Shared Holes: 5H,6H,8H. Feed 12' of string through top center groove from butt of handle to 1HL. Clamp at 1HL. This will be your starting clamp. Feed other end of string through bottom center groove from butt to 1HR. Pull tension and clamp at 1HR. Feed string through 2HR to top right groove at throat through handle, then back through bottom right groove from butt to 3HR. Tension and clamp at 3HR. Feed left side string through 2HL to bottom left groove at throat through handle, then back through top left groove from butt to 3HL. Tension and clamp at 3HL. Feed to 4HL to 1TL. Tension and clamp at 1TL. Feed right side string through 4HR to 1TR. Tension and clamp at 1TR. Install rest of mains and crosses as normal.</p>
--------------	--