

## Racquets

|                            |
|----------------------------|
| Wilson Drone 175           |
| Wilson Lazer Stick BLX 180 |
| Wilson Hit Stick BLX 175   |

| Tension | Pattern | Start M's | Mains Skip |
|---------|---------|-----------|------------|
| 28-33   | 14 x 17 | H         | 7H ONLY    |

|             |         |
|-------------|---------|
| Length 1pc  |         |
| Short Side  |         |
| Length 2pc  | 24'x16' |
| Tie Off M's | 2T      |
|             |         |
| Start 1pc X |         |
| Last 1pc X  |         |
| Tie 1pc X   |         |
|             |         |
| Start 2pc X | 5H      |
| Last 2pc X  | 4T      |
| Tie 2pc X   | 4H, 5T  |

|              |  |
|--------------|--|
| <b>Notes</b> | <p>Shared Holes: 5H,6H,8H. Note 2: Be careful when feeding string through slots in handle to avoid crossing strings. Some stringers may find it necessary to remove the grip to avoid crossing strings. Note 3: Center 8 mains are all pulled from the head (pulling 2 strings at the same time). MAIN STRING INSTALLATION: Step 1: Feed 12' of string from 1HL through bottom throat slot. Clamp at 1HL. This will be your initial clamp. Step 2: Feed other end of string from 1HR through upper throat slot, then wrap around second groove from right at butt to 2HR. Pull tension and clamp at 2HR. Step 3: Feed left side of string around second groove from left at butt to 2HL. Tension and clamp at 2HL. Step 4: Feed Left side of string from 3HL through bottom throat slot, then around left groove at butt to 4HL. Pull tension and clamp at 4HL. Step 5: Feed right side of string from 3HR through upper throat slot, then around right groove at butt to 4HR. Pull tension and clamp at 4HR. Step 6: Finish installing rest of mains and crosses as normal. CROSS STRING INSTALLATION: Note 1: Start X's with hard weave.</p> |
|--------------|--|